

**Thread Repair Workshop Kits**

**Kits Reparadores de Roscado para Taller**

	M	BSW/BSF	UNC/UNF
V-COIL	21	22	22
V-COIL rapid	20		
with Machine Inserting Tool con Herramientas para Insertar Máquina	23-24		



### Thread Repair Workshop Kits V-COIL rapid

Wire Thread Inserts 1,5 D

### Kits Reparadores de Roscado para Taller V-COIL rapid

Insertos Roscados 1,5 D








						Art.-No.	Price €
<b>M 5 - M 12</b>						04381	149,50
M 5 x 0.8	5.2 mm	08093	07093	1/4"	10		
M 6 x 1.0	6.3 mm	08094	07094	1/4"	10		
M 8 x 1.25	8.3 mm	08095	07095	1/4"	10		
M 10 x 1.5	10.4 mm	08096	07096	1/4"	10		
M 12 x 1.75	12.4 mm	08097	07097	1/4"	10		
<b>M 6 - M 10</b>						04385	95,00
M 6 x 1.0	6.3 mm	08094	07094	1/4"	10		
M 8 x 1.25	8.3 mm	08095	07095	1/4"	10		
M 10 x 1.5	10.4 mm	08096	07096	1/4"	10		

## Thread Repair Workshop Kits

### Kits Reparadores de Roscado para Taller








					Art.-No.	Price €
<b>M 5 - M 12</b>					04081	149,50
M 5 x 0.8	5.2 mm	No. 8	No. 8	25		
M 6 x 1.0	6.3 mm	No. 9	No. 9	25		
M 8 x 1.25	8.3 mm	No. 11	No. 11	25		
M 10 x 1.5	10.4 mm	No. 13	No. 13	25		
M 12 x 1.75	12.4 mm	No. 15	No. 15	10		
<b>M 6 - M 14 x 1.25 / NP</b>					04082	164,80
M 6 x 1.0	6.3 mm	No. 9	No. 9	25		
M 8 x 1.25	8.3 mm	No. 11	No. 11	25		
M 10 x 1.5	10.4 mm	No. 13	No. 13	25		
M 12 x 1.75	12.4 mm	No. 15	No. 15	10		
M 14 x 1.25		No. 17		10		
<b>M 6 - M 14 x 1.25 / PT (*Spark Plug / Machos Spark Plug)</b>					04083	170,00
M 6 x 1.0	6.3 mm	No. 9	No. 9	25		
M 8 x 1.25	8.3 mm	No. 11	No. 11	25		
M 10 x 1.5	10.4 mm	No. 13	No. 13	25		
M 12 x 1.75	12.4 mm	No. 15	No. 15	10		
M 14 x 1.25*		No. 17		10		
<b>M 6 - M 10</b>					04085	95,00
M 6 x 1.0	6.3 mm	No. 9	No. 9	25		
M 8 x 1.25	8.3 mm	No. 11	No. 11	25		
M 10 x 1.5	10.4 mm	No. 13	No. 13	25		

## Thread Repair Workshop Kits

### Kits Reparadores de Roscado para Taller








					Art.-No.	Price €
<b>UNC 1/4 - 1/2"</b>					04184	185,40
UNC 1/4 x 20	6.7 mm	No. 9	No. 9	25		
UNC 5/16 x 18	8.3 mm	No. 10	No. 11	25		
UNC 3/8 x 16	9.9 mm	No. 12	No. 12	25		
UNC 7/16 x 14	11.6 mm	No. 14	No. 14	10		
UNC 1/2 x 13	13.0 mm	No. 15	No. 15	10		
<b>UNF 1/4 - 1/2"</b>					04185	185,40
UNF 1/4 x 28	6.7 mm	No. 9	No. 9	25		
UNF 5/16 x 24	8.3 mm	No. 11	No. 11	25		
UNF 3/8 x 24	9.8 mm	No. 13	No. 13	25		
UNF 7/16 x 20	11.5 mm	No. 14	No. 14	10		
UNF 1/2 x 20	13.0 mm	No. 15	No. 15	10		
<b>BSW 1/4 - 1/2"</b>					04186	185,40
BSW 1/4 x 20	6.7 mm	No. 9	No. 9	25		
BSW 5/16 x 18	8.3 mm	No. 10	No. 11	25		
BSW 3/8 x 16	9.9 mm	No. 12	No. 12	25		
BSW 7/16 x 14	11.5 mm	No. 14	No. 14	10		
BSW 1/2 x 12	13.0 mm	No. 15	No. 15	10		
<b>BSF 1/4 - 1/2"</b>					04187	185,40
BSF 1/4 x 26	6.6 mm	No. 9	No. 9	25		
BSF 5/16 x 22	8.3 mm	No. 11	No. 11	25		
BSF 3/8 x 20	9.9 mm	No. 12	No. 12	25		
BSF 7/16 x 18	11.5 mm	No. 14	No. 14	10		
BSF 1/2 x 16	13.0 mm	No. 15	No. 15	10		

**Thread Repair Workshop Kits**  
**with Machine Inserting Tools**  
 and STI-Machine Taps (Spiral Point)

**Kits Reparadores de Roscado para taller**  
**con Herramientas para Insertar Máquina**  
 y Machos Máquina STI (Pasante)



					Art.-No.	Price €
<b>M 5 - M 12</b>					04087	180,00
M 5 x 0.8	5.2 mm	M 5	No. 8	25		
M 6 x 1.0	6.3 mm	M 6	No. 9	25		
M 8 x 1.25	8.3 mm	M 8	No. 11	25		
M 10 x 1.5	10.4 mm	M 10	No. 13	25		
M 12 x 1.75	12.4 mm	M 12	No. 15	10		



## Machine Inserting Tool

with 1/4" Hexagon Drive

## Herramientas para Insertar Máquina

con amarre hexagonal 1/4"



Dimensions	L 1			Art.-No.	Price €
<b>M</b>					
M 3 x 0.5	46	6	1/4"	08070	8,00
M 4 x 0.7	56	7	1/4"	08071	8,00
M 5 x 0.8	62	8	1/4"	08072	8,00
M 6 x 1.0	76	10	1/4"	08073	8,00
M 8 x 1.25	85	12	1/4"	08074	9,80
M 10 x 1.5	96	14	1/4"	08075	10,80
M 12 x 1.75	107	16	1/4"	08076	12,00





## Thread Repair Kits

with Machine Inserting Tool  
and STI-Machine Tap (Spiral Point)

## Kits Reparadores de Roscada

con Herramientas para Insertar Máquina  
y Machos Máquina STI (Pasante)



				Art.-No.	Price €
<b>M</b>					
M 3 x 0.5	3.2 mm	No. 4	20	04070	23,90
M 4 x 0.7	4.2 mm	No. 6	20	04071	23,90
M 5 x 0.8	5.2 mm	No. 8	20	04072	24,70
M 6 x 1.0	6.3 mm	No. 9	20	04073	26,30
M 8 x 1.25	8.3 mm	No. 11	20	04074	33,70
M 10 x 1.5	10.4 mm	No. 13	15	04075	36,40
M 12 x 1.75	12.4 mm	No. 15	10	04076	40,70